


# BNC Series

## RIGHT ANGLE ADAPTOR




### PLUG TO JACK-RIGHT ANGLE

P/N	Cable Group	Impedance
111-R010	N/A	50

# BNC Series


## RIGHT ANGLE ADAPTOR

---



### RIGHT ANGLE PLUG TO JACK

P/N	Cable Group	Impedance
111-R020	N/A	50



### JACK TO JACK PANLE RECEPTACLE

P/N	Cable Group	Impedance
111-R030	N/A	50