



FME Series

IN-SERIES ADAPTOR




FME PLUG TO FME PLUG ADAPTOR

P/N	Cable Group	Impedance
119-A010	N/A	50




FME PLUG TO N PLUG ADAPTOR

P/N	Cable Group	Impedance
119-A301	N/A	50



FME PLUG TO BNC JACK ADAPTOR

P/N	Cable Group	Impedance
119-A316	N/A	75




FME JACK TO MINI-UHF PLUG ADAPTOR

P/N	Cable Group	Impedance
119-A317	N/A	75


FME Series

IN-SERIES ADAPTOR




FME JACK TO BNC PLUG ADAPTOR

P/N	Cable Group	Impedance
119-A319	N/A	50



FME JACK TO MINI-UHF JACK ADAPTOR

P/N	Cable Group	Impedance
119-A322	N/A	50




FME JACK TO SMA JACK ADAPTOR

P/N	Cable Group	Impedance
119-A325	N/A	75


FME Series

IN-SERIES ADAPTOR




RIGHT ANGLE FME PLUG TO BNC PLUG

P/N	Cable Group	Impedance
119-R330		




FME JACK TO BNC JACK

P/N	Cable Group	Impedance
119-A320		



FME PLUG TO MINI UHF JACK

P/N	Cable Group	Impedance
119-A330		



FME PLUG TO BNC PLUG

P/N	Cable Group	Impedance
119-A335		