

IN-SERIES ADAPTOR

ADAPTOR



IN-SERIES ADAPTOR

SMA SERIES

SMA PLUG TO SMA PLUG ADAPTOR **SMA PLUG TO SMA JACK ADAPTOR** **SMA PLUG TO SMA BULKHEAD MOUNT JACK ADAPTOR** **SMA PLUG TO SMA JACK ADAPTOR**



101-A010



101-A020



101-A023



101-A025

SMA PLUG TO UHF PLUG ADAPTOR **SMA PLUG TO UHF JACK ADAPTOR** **SMA PLUG TO MINI-UHF PLUG ADAPTOR** **SMA PLUG TO MINI-UHF JACK ADAPTOR**




101-A090



101-A100



101-A110



101-A120

SMA PLUG TO N PLUG ADAPTOR **SMA PLUG TO N JACK ADAPTOR** **SMA PLUG TO BNC PLUG ADAPTOR** **SMA PLUG TO BNC JACK ADAPTOR**



101-A191



101-A201



101-A210



101-A220

SMA PLUG TO TNC PLUG ADAPTOR **SMA PLUG TO TNC JACK ADAPTOR** **SMA PLUG TO FME PLUG ADAPTOR** **SMA JACK TO MC-CARD PLUG ADAPTOR**



101-A230



101-A240



101-A370



101-A470

IN-SERIES ADAPTOR

SMA SERIES

**SMA PLUG TO U.FL
PLUG ADAPTOR**



101-A522

**SMA PLUG TO GSC PLUG
ADAPTOR**



101-A523

**SMA JACK TO SMA JACK
ADAPTOR**



101-A610

**SMA BULKHEAD JACK TO
SMA JACK ADAPTOR
WITH O-RING SEAL**



101-A611

**SMA BULKHEAD JACK
TO SMA JACK
ADAPTOR**



101-A612

**SMA PANEL MOUNT JACK
RECEPTACLE-4 HOLE SQ.
FLANGE TO SMA JACK
ADAPTOR**



101-A614

**SMA PANEL MOUNT
JACK
RECEPTACLE-2 HOLE SQ.
FLANGE TO SMA JACK
ADAPTOR**



101-A615

**SMA PANEL JACK
4-HOLE TO BLKD JACK
ADAPTOR**



101-A616

**SMA JACK TO SMB PLUG
ADAPTOR**



101-A640

**SMA JACK TO SMB JACK
ADAPTOR**



101-A650

**SMA JACK TO SMC PLUG
ADAPTOR**



101-A660

**SMA JACK TO SMC JACK
ADAPTOR**



101-A670

**SMA JACK TO UHF PLUG
ADAPTOR**



101-A680

**SMA JACK TO UHF JACK
ADAPTOR**



101-A690

**SMA JACK TO
MINI-UHF PLUG
ADAPTOR**



101-A700

**SMA JACK TO
MINI-UHF JACK
ADAPTOR**



101-A710

IN-SERIES ADAPTOR

SMA SERIES

**SMA JACK TO MCX
PLUG ADAPTOR**



101-A720

**SMA JACK TO MCX JACK
ADAPTOR**



101-A730

**SMA JACK TO MMCX
PLUG ADAPTOR**



101-A740

**SMA JACK TO MMCX
JACK ADAPTOR**



101-A750

**SMA JACK TO N PLUG
ADAPTOR**



101-A780

**SMA JACK TO N JACK
ADAPTOR WITH O-RING
SEAL**



101-A791

**SMA JACK TO N JACK
ADAPTOR**



101-A792

**SMA JACK TO
N BULKHEAD JACK
ADAPTOR**



101-A793

**SMA JACK TO N
BULKHEAD JACK
ADAPTOR**



101-A794

**SMA JACK TO N
BULKHEAD JACK
ADAPTOR**



101-A795

**SMA JACK TO BNC PLUG
ADAPTOR**



101-A800

**SMA JACK TO BNC JACK
ADAPTOR**



101-A810

**SMA BULKHEAD JACK
TO BNC JACK
ADAPTOR**



101-A811

**SMA BULKHEAD JACK
TO BNC JACK
ADAPTOR**



101-A812

**PLUG TO (OKI 900)SMA
JACK ADAPTER**



101-A814

**SMA JACK TO BNC
BULKHEAD JACK
ADAPTOR**



101-A815

IN-SERIES ADAPTOR

SMA SERIES

**SMA JACK TO
BNC BULKHEAD JACK
ADAPTOR**



101-A818

**SMA BULKHEAD JACK
TO BNC JACK
ADAPTOR**



101-A819

**SMA JACK TO TNC PLUG
ADAPTOR**



101-A820

**SMA JACK TO TNC PLUG
(EPOXY TYPE)ADAPTOR**



101-A82C

**SMA JACK TO TNC JACK
ADAPTOR**



101-A830

**TNC BULKHEAD JACK
TO SMA JACK
ADAPTOR**



101-A835

**TNC BULKHEAD JACK TO
SMA JACK (EPOXY TYPE)
ADAPTOR**



101-A83C

**SMA JACK TO
MC-CARD JACK
ADAPTOR**



101-A980

**SMA JACK TO
U.FL PLUG ADAPTOR**



101-A990

**SMA JACK TO
GSC PLUG ADAPTOR**



101-A991

**SMA JACK TO
W.FL side JACK ADAPTOR**



101-A992

**SMA JACK TO
W.FL PLUG ADAPTOR**



101-A993

**SMA JACK TO
W.FL JACK ADAPTER**



101-A994

**SMA JACK TO
H.FL PLUG ADAPTOR**



101-A995

**SMA JACK TO
GSC JACK ADAPTER**



101-A996

**SMA JACK TO
U.FL JACK ADAPTER**



101-A997

IN-SERIES ADAPTOR

N SERIES(50 OHM)

**N PLUG TO N PLUG
ADAPTOR**



110-A010

**N PLUG TO N JACK
ADAPTOR**



110-A020

**N PLUG TO BNC PLUG
ADAPTOR**



110-A030

**N PLUG TO BNC PLUG
ADAPTOR**



110-A040

**N PLUG TO TNC PLUG
ADAPTOR**



110-A050

**N PLUG TO TNC JACK
ADAPTOR**



110-A060

**N LUG TO F PLUG
ADAPTOR**



110-A090

**N PLUG TO F JACK
ADAPTOR**



110-A100

**N PLUG TO RCA JACK
ADAPTOR**



110-A120

**N JACK TO N JACK
ADAPTOR**



110-A430

**N PANEL MOUNT JACK
RECEPTACLE-4 HOLE SQ.
TO N JACK ADAPTOR**



110-A433

**N BULKHEAD JACK TO
N JACK ADAPTOR**



110-A434

**N JACK TO BNC JACK
ADAPTOR**



110-A450

**N JACK TO TNC PLUG
ADAPTOR**



110-A460

**N PLUG TO UHF JACK
ADAPTOR**



110-A840

**N PLUG TO
MINI-UHF JACK
ADAPTOR**



110-A860

IN-SERIES ADAPTOR

N SERIES(75 OHM)

**N PLUG TO
MINI-SMB JACK
ADAPTER**



140-A010

**N PLUG TO
MINI-SMB PLUG
ADAPTER**



140-A020

**N PLUG TO F JACK
ADAPTER**



140-A030

**N PLUG TO F PLUG
ADAPTER**



140-A041

**N PLUG TO MCX PLUG
ADAPTER**



140-A050

**N PLUG TO MCX JACK
ADAPTER**



140-A060

**N PLUG TO
1.6/5.6DIN PLUG
ADAPTER**



140-A070

**N PLUG TO
1.6/5.6DIN JACK
ADAPTER**



140-A080

**N PLUG TO BT43 PLUG
ADAPTER**



140-A090

**N PLUG TO BT43 JACK
ADAPTER**



140-A100

**N PLUG TO BNC PLUG
ADAPTER**



140-A110

**N PLUG TO BNC JACK
ADAPTER**



140-A120

**N PLUG TO TNC PLUG
ADAPTER**



140-A130

**N PLUG TO TNC JACK
ADAPTER**



140-A140

IN-SERIES ADAPTOR

BNC SERIES

**BNC PLUG TO BNC
PLUG ADAPTOR**



111-A010

**BNC PLUG TO BNC JACK
ADAPTOR**



111-A020

**BNC PLUG TO F JACK
ADAPTOR**



111-A081

**BNC PLUG TO RCA JACK
ADAPTOR**



111-A100

**BNC PLUG TO FME
PLUG ADAPTOR**



111-A170

**BNC PLUG TO PAL PLUG
ADAPTOR**



111-A230

**BNC PLUG TO
PAL QUICK JACK
ADAPTOR**



111-A240

**BNC JACK TO BNC JACK
ADAPTOR**



111-A410

**BNC JACK TO BNC
BULKHEAD JACK
ADAPTOR**



111-A411

**BNC JACK TO TNC PLUG
ADAPTOR**



111-A420

**BNC JACK TO TNC JACK
ADAPTOR**



111-A430

**BNC JACK TO F PLUG
ADAPTOR**



111-A460

**BNC JACK TO
RCA PLUG ADAPTOR**



111-A480

**BNC JACK TO RCA
JACK ADAPTOR**



111-A490

**BNC JACK TO FME
PLUG ADAPTOR**



111-A560

**BNC JACK TO PAL
PLUG ADAPTOR**



111-A621